



**Notes**

1. Relay amperage = 2 x total Light amperage
2. Relay Fuse amperage = Relay amperage
3. Switch amperage = Relay switching amperage
4. Switch Fuse amperage = Switch amperage
5. Wire aage size determined by amperage araw and aire run length iaw with wire sizing chart (goggle it)

**LEGEND**

- Lower Gage Ground
- Battery Ground
- Power to/from Switch
- Power to/from Relay